


Jump Liners

MIG Welding Accessory

Issued June 2024 • Index No. SPEC JL-1.7

Jump Liner



All Consumables are Not Created Equal.

It's important to choose longer lasting consumables. They can make the difference between repeated consumable replacement and rework, or more arc time and better bottom line.

Jump Liners replace only the most commonly worn and clogged liner area to reduce the amount of time a gun is offline and minimize inventory.

Enable quick and easy neck change-out so gun can be easily adapted to fit multiple applications.

For use with all Bernard® BTB MIG guns with conventional liners and rotatable necks.

Available in sizes to fit .035" (0.9 mm) to 1/16" (1.6 mm) wire.

CALIFORNIA PROPOSITION 65 WARNING

This product contains chemicals, including lead, known to the state of California to cause cancer, and birth defects or other reproductive harm. *Wash hands after use.*

Made with
Pride and without
Compromise in the **USA**

Bernard

An Illinois Tool Works Company
449 West Corning Road, Box 667
Beecher, Illinois 60401 USA

Phone: 800-946-2281 (US Only) 708-946-2281 (Outside US)
Fax: 708-946-6726
For more information, visit us at Tregaskiss.com



Available Jump Liners

PART NO.	ELECTRODE SIZE	LENGTH
QJL-3545	.035" - .045" (.9 mm - 1.2 mm)	14"
QJL-3545-XL	.035" - .045" (.9 mm - 1.2 mm)	27"
QJL-116	1/16" (1.6 mm)	14"
QJL-116-XL	1/16" (1.6 mm)	27"
QJLH-116	1/16" Heavy Duty (1.6 mm)	14"

Installation Instructions

1. Turn off power.
2. Remove nozzle, insulator, contact tip, gas diffuser and neck from gun.
3. Remove old jump liner from the back end of the neck.
4. Insert new jump liner making sure the liner stop is fully seated at back end of neck.
5. Take the tapered end of the neck and insert into the end fitting of the gun handle. Make sure that the liner extruding from the handle is trimmed to 1/4" beyond the gun handle to ensure proper fit up to new jump liner. Secure the neck to the gun by turning the insulated nut clockwise.
7. Trim the liner at the nozzle of the neck as follows:
 - D-A1-C and D-A2-C AccuLock S gas diffuser = 3/4"
 - DS-A1-C and DS-A2-C AccuLock S gas diffuser = 5/8"
 - DS-1 and D-1 Centerfire gas diffuser = 9/16"
 - All Tough Lock retaining heads = 3/4"
 - D118Q Quik Tip gas diffuser = 7/8"
 - D114Q Quik Tip gas diffuser = 3/4"
 - 4235 and 4635 Elliptical gas diffuser (used with 1500 series contact tips) = 3/8"
 - 4335 and 4435 gas diffuser (used with 7400 series contact tips) = 1-3/8"
8. File the cut end of the liner to eliminate burrs.
9. Reinstall the cap, gas diffuser, contact tip and nozzle.

